

Tools Required

- 7/16" Wrench (not included)

Installation

- Insert Carriage Bolts through square holes of Bottle Holder.
- Orient Bottle Holder in direction shown below.
- Insert Carriage Bolts through holes on back of Lower Horizontal.
- Use 7/16" Wrench to tighten nuts firmly.



Additional Instructions

- Remove road debris off nuts and bolts to prevent corrosion.
- Inspect hardware on Rack periodically to ensure proper working conditions.
- Certain car wash chemicals may damage Rack finish. Please use caution when cleaning vehicle and/ or Rack.

Questions or comments? Contact our support team via email at email@1up-usa.com