

In the Box:

- RS Hook
- Installation Hardware


Tools Required:

- Drill
- 1/4" Drill Bit
- 1/2" Socket and Ratchet
- Tape Measure
- Level



Installation

- Begin by finding wall location to install. Unit includes mounting hardware for wood construction.
- Use tape to mark and drill 1/4" pilot hole in wall for mounting.
- Use supplied lag and washers to install unit. Lag should be tightened firmly.



Hardware Install Details

Additional Instructions

- Use **caution** while taking steps to install RS Hook.
- Additional hardware included to join RS Hook to RS Shelf if applicable.

Questions or comments? Contact our support team via email at email@1up-usa.com

Warning/Disclaimer

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect mounting, improper use, inadequate maintenance, or neglect of this system.

Manufactured by: 1UP USA