




Equip-D LED/Plate Holder

Tools Required

- 5/16 Allen Wrench (not included)
- 5/32 Allen Wrench (included)

Installation




- Remove all four bolts holding End Cap on.
- Slide unit into place and reinstall four bolts. Tighten firmly.
- Use both preinstalled button head fasteners to install license plate (if applicable).
- Plug Flat 4-pin trailer connector into vehicle (if applicable).


Note: Large hole used to install security lock (sold separately).

Rotating Unit


- Depending on which position your base racks is set at, all units can be adjusted to match. To do so, compress both silver buttons and rotate to desired position. Be sure buttons click into place.



Storage Position




Load Position




Extra Clearance Position


Available Models



License Plate Holder



LED Light Bar & Plate Holder




LED Light Bar Holder


LED Light Bar Functionality

Vehicle Lights On


Running Lights




Right Blinker (Right Side Blinks)



Left Blinker (Left Side Blinks)



Flashers (Both Sides Blink)



Vehicle Lights Off

Right Blinker (Right Side Blinks)



Left Blinker (Left Sides Blink)



Flashers (Both Sides Blink)



Additional Instructions

- Remove road debris off nuts and bolts to prevent corrosion.
- Inspect hardware on accessory periodically to ensure proper working conditions.
- Certain car wash chemicals may damage finish. Please use caution when cleaning vehicle and/ or accessory.

Questions or comments? Contact our support team via email at email@1up-usa.com




Equip-D LED/Plate Holder

Tools Required

- 5/16 Allen Wrench (not included)
- 5/32 Allen Wrench (included)

Installation




- Remove all four bolts holding End Cap on.
- Slide unit into place and reinstall four bolts. Tighten firmly.
- Use both preinstalled button head fasteners to install license plate (if applicable).
- Plug Flat 4-pin trailer connector into vehicle (if applicable).


Note: Large hole used to install security lock (sold separately).

Rotating Unit


- Depending on which position your base racks is set at, all units can be adjusted to match. To do so, compress both silver buttons and rotate to desired position. Be sure buttons click into place.



Storage Position




Load Position




Extra Clearance Position


Available Models



License Plate Holder



LED Light Bar & Plate Holder




LED Light Bar Holder


LED Light Bar Functionality

Vehicle Lights On


Running Lights




Right Blinker (Right Side Blinks)



Left Blinker (Left Side Blinks)



Flashers (Both Sides Blink)



Vehicle Lights Off

Right Blinker (Right Side Blinks)



Left Blinker (Left Sides Blink)



Flashers (Both Sides Blink)



Additional Instructions

- Remove road debris off nuts and bolts to prevent corrosion.
- Inspect hardware on accessory periodically to ensure proper working conditions.
- Certain car wash chemicals may damage finish. Please use caution when cleaning vehicle and/ or accessory.

Questions or comments? Contact our support team via email at email@1up-usa.com