




LICENSE PLATE HOLDER & LED LIGHT BAR


Tools Required

- Security Wrench (not included)
- 5/32 Allen Wrench (included)


LICENSE PLATE HOLDER & LED LIGHT BAR



LICENSE PLATE HOLDER




LED LIGHT BAR




Installation

- Partially thread supplied Security Bolts into Tap Plate.
- Place unit over Security Bolts and slide into keyhole. Tighten with Security Wrench.
- Remove pre-installed button heads and reinstall with license plate (if applicable).
- Plug LED Light Bar into 4-pin trailer connector on vehicle (if applicable).






Ramp Installation (if applicable)

- Partially thread Security Bolts into tapped bar. (Provided with Ramp)
- Place Ramp over Security Bolts and slide into keyhole. Tighten with Security Wrench.



Rotating Unit


- Depending on which position your base rack is set at, all units can be adjusted to match. To do so, compress both silver buttons and rotate to desired position. Be sure buttons click into place.




LED Light Bar Functionality

Vehicle Lights On


Running Lights




Right Blinker (Right Side Blinks)



Left Blinker (Left Side Blinks)



Flashers (Both Sides Blink)



Vehicle Lights Off

Right Blinker (Right Side Blinks)



Left Blinker (Left Sides Blink)



Flashers (Both Sides Blink)



Additional Instructions

- Remove road debris off nuts and bolts to prevent corrosion.
- Inspect hardware on accessory periodically to ensure proper working conditions.
- Certain car wash chemicals may damage finish. Please use caution when cleaning vehicle and/ or accessory.

Questions or comments? Contact our support team via email at email@1up-usa.com