




RAKATTACH XL FITMENT



DRIVER




PASSENGER




NOTE: UNIT IS DIRECTIONAL, PASSENGER SHOWN FOR FITMENT.

RAKATTACH XL FITMENT



NOTE: JACK SHOWN IN DEFAULT MOUNTING POSITION, SEE INSTRUCTIONS FOR ALTERNATIVE MOUNTING.

RAKATTACH XL FITMENT



NOTE: SUPER DUTY RACK SHOWN WITH TRAYS IN WIDE POSITION.